COMPASS[®] for molbox[™]

1204(052) 56-5583 Voltage 4-1684

Dett

Calibration assistance software for molbloc/molbox[™] users

Features

58.2562 slm

- Usable on any IBM-PC or compatible computer with an available COM port and running Windows 95 or higher.
- Supports both molbox1 and molbox RFM.
- A true Windows* application following Windows protocol for file management, menu and message formatting, graphics and editing. Other applications can be run without interrupting test execution.
- Complete online Help facility with Tool Tips.
- Customizable user interface with scalable windows.

- Calibrate and test a wide variety of devices including: MFCs, MFMs, rotometers, turbine meters, bubble meters and others.
- Fully automated testing of both analog and digital MFCs.
- Automated flow control support for testing flow measure only devices.
- Flow corrections with automated ambient pressure and temperature entry for density dependent DUTs.
- Log extra data from the DUT during the test with user defined commands.
- Open hardware configuration allows simple integration of third party acquisition, control, and pressure and temperature measurement hardware.

• Sets up and maintains DUT database with unique DUT characteristics, test scripts and histories.

FLUKE

Calibration

- Process gas editing tool includes complete gas conversion factors for most major MFC manufacturers and automatically calculates conversion factors for missing relationships and blends.
- Produces standard, delimited test data files which easily import into other software programs if desired.
- Test data files stored in user definable directory structure.
- 100% customizable test report generation tool with preformatted templates.
- Extensive on-board plotting function to create a variety of test date plots.

Why COMPASS for molbox

The DHI molbloc/molbox is a unique gas flow standard offering state of the art metrology from <1 sccm to several thousand slm with a wide variety of gases and real time measurement capability. COMPASS for molbox software works with molbloc/molbox to create a full function calibration system. The result is the optimal flow calibration system combining the outstanding performance of molbloc/molbox with the power, versatility and features of a modern PC based application.

Setting up devices to be tested (DUTs)

Individual device under test (DUT) profiles are defined and stored in the DUT database. The DUT profile identifies the test device and specifies all of its operating characteristics. For density dependent devices such as rotameters and turbine meters, the normal operating conditions are specified.

Manufacturer specific gas conversion factor tables are automatically

searched to suggest the appropriate surrogate gas for calibration and a gas conversion factor for use with MFCs and MFMs.

A test script from the test database (see below) is specified in the DUT profile assuring that when the DUT to be tested is selected, the correct test sequence and parameters are used.

DOT RECORD HERE	E-rangile V DUT			HD 8	9 - X	
Values DUT	2/9	ل ل	1	Ø		
Constant Re	nge Tolerance T	et Continu	al Read	Sec.1		
- Margaretter	and research to	and second		San Ste		
OUT Internation	Record Type			1		
	Contraction of the	ndividual		- 22	-	
	and the second	LENERIC			- 2	
	and the second second second	H			1	
	CONTRACTOR CONTRACTOR	776		_	6	
		1,8974				
	Process Gas	42 Nilrogen			•	
	Approximent of the	at meroyen		_	100	

UT record label	Example V DU	r	_	回 B B P X	
Vassing DUT	2/9	ا ل	1	Ø	
Conection Mar	nge Tolerance	Test Condition	ns Read	Set 1	
Internation			outours).	karingti.	
1. Instantiation	Record Type	Individual	_	-	
	Manufactures	DENERIC			
	Model	6-1		*	
	Senal Number	1778			
	Identification	111504			
	Process Gas	N2 Nilrogen		*	

Setting up test definitions

Test scripts are defined and stored in the test database. The test array specifies the test increments to be run and can be filled in automatically. Other user specified test parameters include:

- Run gas purge sequence before the first test point
- Run leak test of system plumbing before the first test point
- Tare molbox at specified test points
- Change molblocs between test points
- Manual or automated flow control
- Flow stability required to take data
- Dwell time at each point prior to taking data
- Time of averaging period over which to take data or user triggered start/stop
 Number of independent readings to take at
- Number of independent readings to take at each point
- Number of complete test cycles to run

	Test white sharings Int D III -> X
Vaning Test 12/23	' 비 비 비 D
Gen (SOUTH)	et Points Seamon Tee Contal Last Test Page Data
110 4 10	Stability (RD JTFS) D.CT as St. etcands
21 (X 13) 31 (4) 13)	Macilly Thrend III 45
4 KK 10	Two mobiles atselected points =
1 13 44 14	Dvellat B Taxed -
51 per 171	Averaging Time (1) [25 Taned _
UI 13	Readings/Pt fr
31 201	Test System [5
in the	-14 I.





Running tests

COMPASS can run predefined test scripts or under direct operator control.

Running a test script starts by selecting a DUT to be tested. Once the DUT is selected, the user may elect to run the test script associated with that DUT or another test selected from the test script database. After initialization, test execution begins. In executing the test, COMPASS supports the maximum level of automation the data acquisition and control hardware and the DUT will allow. When running DUTs that do not control flow (such as rotometers or turbine meters), an independent mass flow controller (MFC) can be interfaced with COMPASS to automate flow control.

While running a test, complete operating information is available through six display windows that can be turned on/off and scaled at will. These include real time readings from the molbox and the DUT, calculated errors and deviations, error plotting and a point by point data grid. The current test definition and DUT profile can be accessed by clicking icons.

A status bar continuously indicates the current activity of test program.

After the last test point, the flow is set to zero and a comment field is presented for entering comments specific to the test. The comments are stored with the test data file.



Flate	0.0002 scem @	0.000/8	
Flow	3.001 scom @	0.00C/s	
Reynolds faimber	30.06	KFactor	1.000000
Upstream Pressure	127.452 kPa	Gas	NZ
Downstream Pressure	97.141 kPa		2 009
Differential Pressure	30.314 kPa		
Temperature	23.12 C	molbio	c (A)1348
Set		Dudebbe	
Output		Switchbox 1.1	

Aut	日日の
4.000 to	con @ 0.00C
DUE Output	2000 Y
Pietsae	
Temporalian	N.G.
Set Point	
Measured Set Point	N/A
	Extra Diata
11-2.000 V	61
21 -0-202 V 31	和 7) 年 日
	61
4) 5	
51	10)

Data handling and report generation

For each test a data file is automatically created and named. The data files are stored following the user specified path to a single directory or to subdirectories by DUT serial or ID number. This gives the user complete control over data file storage including storing to a LAN or intranet if desired. The data file contains exhaustive information and data from the test. This includes complete DUT, calibration standard and test sequence information as well as all of the raw and calculated data collected during test execution. The data file is delimited (by comma, tab or semi-colon) so that it can easily be imported into third party applications for further analysis, manipulation or storage.



Setting up devices to be tested (DUTs)

COMPASS includes a Report Editor to allow final, formatted test reports to be produced within the COMPASS environment. The Report Editor is template based. Several standard templates are included. Custom templates can be created from scratch or by editing existing templates. All the data file variables as well as COMPASS plots can be embedded into the template.

A PLOT function is also included to generate a variety of detailed error plots from data files. Extensive customization is supported. The plots can be created, viewed and printed.





Electronic interfaces supported by COMPASS®

molbox and auxiliary device interfaces: RS-232 IEEE488¹ DUT interfaces: RS-232 RS485² IEEE488¹ DEVICENET³

¹ National Instruments or CEC interface hardware required.

² Requires RS485 to RS-232 converter
 ³ National Instruments or SST interface hardware required.

Ordering information

Model

COMPASS for molbox Flow calibration software

Includes: COMPASS for molbox for Windows is delivered on CD with a user's manual. An install/uninstall tool is included.

S stem requirements: Recommended system configuration to run COMPASS for molbox is: IBM PC compatible computer, 200 MHz, 32 Mb RAM, running Windows 95 or higher (32 bit) with available COM port; Access to CD drive to load COMPASS for molbox; molbox1 or molbox RFM based mass flow standard.

Fluke. Keeping your world up and running.®

Fluke Calibration

PO Box 9090, Everett, WA 98206 U.S.A. Fluke Europe B.V. PO Box 1186, 5602 BD Eindhoven, The Netherlands

For more information call: In the U.S.A. (800) 443-5853 or Fax (425) 446-5116 In Europe/M-East/Africa +31 (0) 40 2675 200 or Fax +31 (0) 40 2675 222 In Canada (800)-36-FLUKE or Fax (905) 890-6866 From other countries +1 (425) 446-5500 or Fax +1 (425) 446-5116 Web access: http://www.fluke.com

©2010 Fluke Calibration. Specifications subject to change without notice. Printed in U.S.A. 7/2010 3029369B B-EN-N

Modification of this document is not permitted without written permission from Fluke Calibration.