



RACK MOUNT KIT, P/N 401929, INCLUDES

QTY	PART NO	FIGURE CALLOUT	DESCRIPTION
1	123699	1	Front panel
2	124155	2	Side bracket
4	100972-Z	3	M4 hex nut
4	102668-Z	4	M4 split lock washer
4	101016-Z	5	M4 x 12 SHC screw
4	100918-Z	6	M4 flat washer
1	123703	7	Rear support bracket
1	123764-01	8	Foam gasket
4	103448-Z	N/A	M3 x 12 self-tapping screw




Figure 1. Rack Mount Kit




Figure 2. Rear Support Bracket and Foam

INSTALLATION INSTRUCTIONS

- 1 Remove the four feet from the bottom of the RPM4™ by removing the screw and then removing the foot. Replace the screw with the shorter M3 x 12 self-tapping screw included in this kit. Repeat for the other three feet.
- 2 Place one side bracket (2) on each side of the RPM4. Position each bracket with the front panel attachment flange (flange with two holes) facing the front of the RPM4.
- 3 Attach the front panel (1) to the side brackets (2) using four M4 split lock washers (4) and four M4 hex nuts (3). Recommended torque is 3 Nm.
- 4 Remove adhesive backing from foam strip (8). Adhere the foam strip to the rear support bracket (7), centering the foam as shown in figure 2.
- 5 Attach the rear support bracket (7) to the side brackets (2) using four M4 flat washers (6) and four M4 X 12 SHC screws (5). Recommended torque is 3 Nm.
- 6 For adequate support of the RPM4, the rear support bracket (7) shall be supported on the side rails of the rack system or by other means.